



SUSTAINABLE ACOUSTICAL COMFORT



SUSTAINABLE, ACOUSTICAL, AND COMFORTABLE UNDERLAYMENT

NO.2026

DURAPAD™

UP TO IIC 72

QUICK AND EASY TO INSTALL

CARPET TILE INSTALLATION PROCEDURE

- 1 Make sure the subfloor is clean and dry.
- 2 Adhere DURAPAD 2MM down to the subfloor with the use of a high-performance carpet adhesive and using the correct trowel*. Always install with the black side down. To minimize flanking, leave a small excess of underlayment around the perimeter of the installation. At corners, gently bend the underlayment so a portion curves up the wall.
- 3 DURAPAD 2MM seams must be placed tightly together and preferably taped with duct tape.
- 4 Adhere DURAPAD 2MM to the carpet tile with the use of a high-performance carpet adhesive and using the correct trowel*. Always install with the black side down.
- 5 After the finished flooring is installed, carefully trim the excess underlayment along the perimeter so it sits flush with the floor surface. Always follow the flooring manufacturer's specifications.



Caution:

Using poor quality adhesive, incorrect type, or improper application method can cause installation issues.

When following the double glue-installation procedure, consider using a 1/8" x 1/8" x 1/8" U-notch trowel for even adhesive coverage.

VINYL FLOOR INSTALLATION PROCEDURE

- 1 Subfloor must be clean, dry, and checked for excessive moisture. A waterproof membrane may be required.
- 2 For floating (click-lock LVP or LVT) installations, roll out DURAPAD 2MM perpendicular to the direction of the flooring. Butt the edges of each row together without overlapping. Use duct tape to secure the seams. Trim the underlayment around walls and obstacles using a utility knife. Always follow the flooring manufacturer's specifications.
- 3 For glue-down (LVP or LVT) installations, roll out DURAPAD 2MM in the same manner as above. Secure the underlayment with a urethane based adhesive. Tape all seams tightly with duct tape, and allow the underlayment to settle as per adhesive curing time. Use the specified adhesive and trowel size, and follow the flooring manufacturer's specifications when adhering LVP/LVT to DURAPAD 2MM.

WARRANTY

Dura underlayments are warranted to retain their essential firmness, resilience, and porosity through the useful life of the floor covering under which they are installed. This warranty applies to all types of indoor installations. In the event of a confirmed product failure due to defective manufacture the company will replace, without charge, the defective portion of the underlayment with new equivalent product.

This warranty is valid only when the product is used in accordance with our instructions and for its intended purpose and does not cover defects or failures due to inappropriate use or abuse.



Find us in
MasterSpec[®]
Powered by Deltek Specpoint[®]



DISCOVER MORE

DURABLE ACOUSTICAL COMFORT



For Engineered Hardwood and Laminated Flooring

YOU NEED:
DURA-SON
DURA-SON MB

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



For Carpet & Carpet Tile

YOU NEED:
DURACUSHION (Carpet)
SUPERDURA (Carpet)
PROTECTOR (Carpet)
DURALUX (Carpet)

DURAPAD (Carpet Tile)
DURAQUIET (Carpet Tile)

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC

The durability of our products are the solution to all your acoustical needs. They will outlast and maintain their acoustical and comfort qualities throughout their lifetime.



For Ceramics

YOU NEED:
DURAQUIET

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



For Vinyl

YOU NEED:
DURAPAD (LVT/LVP)
DURAQUIET (LVT/LVP/Sheet Vinyl)

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



SUSTAINABLE ACOUSTICAL COMFORT

**8525 CHEMIN DELMEADE, MONTREAL
QC H4T 1M1**

1-800-295-4126

INFO@DURAUNDERCUSHIONS.COM

WWW.DURACUSHION.COM

