



SUSTAINABLE ACOUSTICAL COMFORT



SUSTAINABLE, ACOUSTICAL, AND COMFORTABLE UNDERLAYMENT

NO.2026

DURACOUSTIC™

UP TO IIC 92

QUICK AND EASY TO INSTALL

INSTALLATION PROCEDURE

① The subfloor must be structurally sound, flat, clean, and dry.

② Install DURACOUSTIC with black side down. Seams must be placed tightly together and preferably taped with duct tape.

③ Install polyethylene foam or fiberglass board along the wall perimeter of the entire subfloor and around any protrusions at the perimeter. The isolation of the floating floor prevents flanking between floors and walls. Tape or tack-glue the isolation.

④ **A**
For gypsum concrete:
When a gypsum concrete overlay is poured, please refer to supplier's instructions.

B
For cement boards:
Install two layers of 1/2" cement board perpendicularly with a 1/4" gap, and an 8" minimum overlap. Use 2" fiberglass tape embedded in ceramic.

C
For plywood:
The two layers must be glued together using a 1/4" square trowel for full coverage. Leave 1/4" of space all around the perimeter of the floor and fill the gap with acoustical sealant. Always follow the flooring manufacturer's specifications.

Caution:

Using poor quality adhesive, incorrect type, or improper application method can cause installation issues. Please contact Dura Undercushions for installation assistance.



WARRANTY

Dura underlayments are warranted to retain their essential firmness, resilience, and porosity through the useful life of the floor covering under which they are installed. This warranty applies to all types of indoor installations. In the event of a confirmed product failure due to defective manufacture the company will replace, without charge, the defective portion of the underlayment with new equivalent product.

This warranty is valid only when the product is used in accordance with our instructions and for its intended purpose and does not cover defects or failures due to inappropriate use or abuse.



DISCOVER MORE

DURABLE ACOUSTICAL COMFORT



For Engineered Hardwood and Laminated Flooring

YOU NEED:
DURA-SON
DURA-SON MB

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



For Carpet & Carpet Tile

YOU NEED:
DURACUSHION (Carpet)
SUPERDURA (Carpet)
PROTECTOR (Carpet)
DURALUX (Carpet)

DURAPAD (Carpet Tile)
DURAQUIET (Carpet Tile)

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC

The durability of our products are the solution to all your acoustical needs. They will outlast and maintain their acoustical and comfort qualities throughout their lifetime.



For Ceramics

YOU NEED:
DURAQUIET

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



For Vinyl

YOU NEED:
DURAPAD (LVT/LVP)
DURAQUIET (LVT/LVP/Sheet Vinyl)

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



SUSTAINABLE ACOUSTICAL COMFORT

**8525 CHEMIN DELMEADE, MONTREAL
QC H4T 1M1**

1-800-295-4126

INFO@DURAUNDERCUSHIONS.COM

WWW.DURACUSHION.COM

