

DURA



DURABLE, ACOUSTICAL, AND COMFORTABLE UNDERLAYMENT

NO.2023-01

DURALUX

QUICK AND EASY TO INSTALL

TACKLESS AND STRETCH-IN INSTALLATION PROCEDURE

1
Measure the length and width of the room and cut DURALUX to size, leaving a 1/2" gap around the perimeter of the room.

2
DURALUX should be laid black side down. Ensure that it covers the entire area of the room.

3
Use double-sided carpet tape to secure the edges of DURALUX to the floor along the perimeter of the room, leaving a 1/2" gap around the edges.

4
Install tack strips around the perimeter of the room, making sure to leave a 1/4" gap between the strip and the wall.

5
Stretch the carpet over DURALUX and tuck the carpet into the gap between the tack strip and the wall using a knee kicker or power stretcher.

6
Use a carpet knife to trim any excess carpet along the edges of the room.



Caution:

Using poor quality adhesive, incorrect type, or improper application method can cause installation issues. Please contact Dura Undercushions for the installation of DURALUX using the double-glue procedure.

When following the double glue-installation procedure, consider using a 1/8" x 1/8" x 1/8" U-notch trowel for even adhesive coverage.

DISCOVER MORE

DURABLE ACOUSTICAL COMFORT



For Engineered Hardwood and Laminated Flooring

YOU NEED:
DURA-SON
DURA-SON MB

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



For Carpets

YOU NEED:
DURACUSHION
SUPERDURA
PROTECTOR
DURALUX

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC

The durability of our products are the solution to all your acoustical needs. They will outlast and maintain their acoustical and comfort qualities throughout their lifetime.



For Ceramics

YOU NEED:
DURAQUIET

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



For Vinyl

YOU NEED:
DURAQUIET

MULTI-RESILIENT LAYER FLOORING

YOU NEED:
DURACOUSTIC



**8525 CHEMIN DELMEADE, MONTREAL
QC H4T 1M1**

1-800-295-4126

INFO@DURAUNDERCUSHIONS.COM

WWW.DURACUSHION.COM

