



DURABLE ACOUSTICAL COMFORT



DURABLE, ACOUSTICAL, AND COMFORTABLE UNDERLAYMENT

NO.2025-01

DURAQUIET™

UP TO IIC 74

QUICK AND EASY TO INSTALL

CERAMIC AND NATURAL STONE TILE INSTALLATION PROCEDURE

- 1**
Follow ceramic and natural stone tile manufacturer's instructions.
- 2**
Installation and subfloor requirements must conform to TCA or TCC standards.
- 3**
Concrete subfloor must be clean, dry, and checked for excessive moisture. A waterproof membrane may be required.
- 4**
Areas requiring fill patching or levelling must be prepared using a self-levelling underlayment.
- 5**
Install a perimeter isolation strip or foam along the wall perimeter of the entire subfloor and around any protrusions at the perimeter.
- 6**
Adhere DURAQUIET using a urethane-based adhesive, butt the seams together, ensuring not to overlap the membrane.
- 7**
Immediately roll the floor using a 50-75 lb. roller to ensure proper adhesive transfer, starting with the width and then the length.
- 8**
Apply dry-set mortar over DURAQUIET, as directed by mortar manufacturer.
- 9**
Grout tiles using a polymer-modified grout or a 100% solids epoxy grout.

Caution:

Gypsum concrete underlayment must first be sealed with floor sealer before applying any moisture cured urethane adhesive. Using poor quality adhesive, incorrect type, or improper application method can cause installation issues. Please contact Dura Undercushions for installation assistance.



VINYL FLOOR INSTALLATION PROCEDURE

- | | | | | | |
|--|--|--|--|---|---|
| <p>①</p> <p>Concrete subfloor must be clean, dry, and checked for excessive moisture. A waterproof membrane may be required.</p> | <p>②</p> <p>Areas requiring fill patching or levelling must be prepared using a self-levelling underlayment.</p> | <p>③</p> <p>Adhere DURAQUIET using a urethane-based adhesive, butt the seams together, ensuring not to overlap the membrane.</p> | <p>④</p> <p>Immediately roll the floor using a 50-75 lb. roller to ensure proper adhesive transfer, starting with the width and then the length.</p> | <p>⑤</p> <p>Seal DURAQUIET with a moisture cured urethane adhesive.</p> | <p>⑥</p> <p>Adhere the vinyl tile or floor to DURAQUIET using the recommended acrylic adhesive by the vinyl manufacturer.</p> |
|--|--|--|--|---|---|

WARRANTY

Dura underlayments are warranted to retain their essential firmness, resilience, and porosity through the useful life of the floor covering under which they are installed. This warranty applies to all types of indoor installations. In the event of a confirmed product failure due to defective manufacture the company will replace, without charge, the defective portion of the underlayment with new equivalent product.

This warranty is valid only when the product is used in accordance with our instructions and for its intended purpose and does not cover defects or failures due to inappropriate use or abuse.



Find us in
MasterSpec®
Powered by Deltek Specpoint®



DISCOVER MORE

DURABLE ACOUSTICAL COMFORT



For Engineered Hardwood and Laminated Flooring

YOU NEED:

DURA-SON
DURA-SON MB

MULTI-RESILIENT LAYER FLOORING

YOU NEED:

DURACOUSTIC



For Carpet & Carpet Tile

YOU NEED:

DURACUSHION (Carpet)
SUPERDURA (Carpet)
PROTECTOR (Carpet)
DURALUX (Carpet)

DURAPAD (Carpet Tile)
DURAQUIET (Carpet Tile)

MULTI-RESILIENT LAYER FLOORING

YOU NEED:

DURACOUSTIC

The durability of our products are the solution to all your acoustical needs. They will outlast and maintain their acoustical and comfort qualities throughout their lifetime.



For Ceramics

YOU NEED:

DURAQUIET

**MULTI-RESILIENT
LAYER FLOORING**

YOU NEED:

DURACOUSTIC



For Vinyl

YOU NEED:

DURAPAD (LVT/LVP)

DURAQUIET (LVT/LVP/Sheet Vinyl)

**MULTI-RESILIENT
LAYER FLOORING**

YOU NEED:

DURACOUSTIC



DURABLE ACOUSTICAL COMFORT

**8525 CHEMIN DELMEADE, MONTREAL
QC H4T 1M1**

1-800-295-4126

INFO@DURAUNDERCUSHIONS.COM

WWW.DURACUSHION.COM

